




What's inside:


- 1




1x Gateway


 1x Power Adapter


 1x Ethernet Cable
- 2




1x Wi-Fi Camera


 1x Power Adapter


 Mounting Accessories
- 3




1x Alarm Keypad


 2x Double-Sided Tapes


 Mounting Accessories
- 4




4x Door + Window Sensors


 4x Batteries (CR123A)


 8x Double-Sided Tapes
- 6




1x Infrared Motion Sensor


 1x Battery (CR123A)


 1x Double-Sided Tape
- 5



1x External Siren

 6x Mounting Accessories

 1x Double-Sided Tape
- 7




2x Arm/Disarm/Panic Remotes

Broadband internet connection, iOS or Android phone and home router required.

Step 1: Connect to Network

Unpack all of your hardware within 20 feet of your home router for quick set up.

1. Connect the 1 Gateway to your router with the included Ethernet cable, then power on.




2. Install batteries and plug in power adapters to devices and sensors.



Step 2: Set up your smartphone

1. Go to Wi-Fi settings and connect your smartphone to Wi-Fi.



2. Download the Home8 app from the App Store or Google Play Store.




Step 4: Place your devices

Wi-Fi Camera


Connect the included power adapter and ethernet cable (optional) to the 2 Camera.

Check the Light indicators. The up light should be Solid red as power on. The button light should be blink green if camera is within the signal range.




Alarm Keypad

Double-sided tape to mount Keypad on a wall near a door you use when you leave the property. Please refer to "Alarm Keypad Instruction" for more detail.




3. Follow the on-screen instructions and set up your account.




Step 3: Activate your system


1. Select Menu Icon ≡ on top left on the App and tap "Add Device" to activate system.



2. Find the QR Code Sticker on the Gateway and follow the instructions on your app.




3. When you see the "System is ready!" message. Congratulations, your system setup has completed!



Step 4: Place your devices


Door + Window Sensor

Use screws or Double-sided tape to attach sensor.
Maximum distance between two part is 1/4 inch .




Infrared Motion Sensor

Place the device in an area with no direct sunlight.
The motion sensor has a 3 minutes cooldown period.




External Siren

Plug the power line.
Place the siren.



Use your Keychain Remote to Arm/Disarm/Panic


Press the Arm/Disarm button.
The LED light should blink.
You will receive a push notification on your phone saying "System is armed/disarmed by keychain remote" if remote is within range.




Hold either button for 5 seconds as trigger Panic button.

Step 5: Enable your service


1. On the home screen, tap the **Subscribe Now**.




Once your subscription is successful, the system status will change to "**Practice Mode**" for one day.



2. Provide contact and payment method information.



With our Professional Monitoring Service, after the 1-Day Practice Period, the system status will change to "**In Service**", you'll receive 24/7 monitoring for your system.




3. Review order information and click **Place Order**.

Troubleshooting & FAQ

Please visit <https://www.home8alarm.com/faq/> or call 1-844-800-6482 for more information.

Alarm Keypad Instruction




- 1. **Green LED**
Normal On :
Power on
- 2. **Blue LED**
Flashes Once :
Arm / Stay or Disarm
- 3. **Red LED**
Flashes Once :
Wrong programming
Flashes Once Every 3 Seconds :
Low battery indication, please replace the batteries.
- 4. Wake Up Key
- 5. Arm
- 6. Arm in Stay Mode
- 7. Disarm
- 8. SOS Key
- 9. Battery Slot
- 10. Wired Cables Interface
- 11. **Tamper Switch**
The tamper switch will be activated if case is opened
- 12. Screw Hole
- 13. Rear Cover
- 14. Wired Cables Interface

Operation

Please follow the instructions below to operate the keypad.

Press "*" to activate keypad then enter **admin password #** or **user password #** before operating.



- **Admin password** is **123456** as default
- **User password** is **1234** as default

Note: If there is no operations within 5 seconds after pressing "*", keypad will exit setup state automatically.

Function	Press Button
Arm	Press * + 1234 + [lock icon]
Arm in Stay	Press * + 1234 + [home icon]
Disarm	Press * + 1234 + [open lock icon]

Function	Press Button
Mute	Press [home icon] button, then press [open lock icon] within 1 second to enter Siren Delay - "No Siren - Exclude Emergency Events" mode.
Unmute	Press [home icon] button, then press [open lock icon] within 1 second to cancel Siren Delay mode.
SOS Emergency Call	Press SOS for 3 seconds to activate an immedate alarm.

Note: It is recommended to enable function of **Emergency Call with Password** to avoid false operation. See Settings.

Settings

Please follow the instructions below to program the keypad settings.

Press " * " then enter **admin password # 9** to enter setting state. Blue LED will light up. Then insert your command.

*

+

admin password


+

#

+

9

- **Admin password** is **123456** as default.
 - Keypad will be programmed successfully after one beep is heard.
- Note: No operation within 30 seconds, keypad will automatically exit setup state.

Function	Remark
Press Button	
Quick Arm On	Once enabled, users can press " * +  " to arm the system without password.
<div><div>*</div><div>1</div><div>#</div></div>	

Function	Remark
Press Button	
Quick Arm Off	—
<div><div>*</div><div>1</div><div>*</div></div>	
Touch Tone On	—
<div><div>*</div><div>2</div><div>#</div></div>	
Touch Tone Off	Once enabled, the green LED will flash when a button is pressed.
<div><div>*</div><div>2</div><div>*</div></div>	

Function	Remark
Press Button	
Emergency Call with Password	—
<div><div>*</div><div>4</div><div>#</div></div>	
Emergency Call without Password	—
<div><div>*</div><div>4</div><div>*</div></div>	
Change Admin Password	6 digits
<div><div>*</div><div>new password</div><div>#</div></div>	

Function	Remark
Press Button	
Change User Password	4 digits
<div><div>*</div><div>new password</div><div>#</div></div>	
Arm Delay	(0-99s)
<div><div>0-99s</div><div>#</div></div>	

Reset to Default Settings

Press the **Tamper Switch 5 times** in a row, then you will heard one long beep.