



Panoramic Talking Camera (Twist HD Camera)

IPC2201



User Manual

home8.com

1-844-800-6482 | support@home8alarm.com

Table of Contents

Chapter 1. Introduction.....	1
1.1 System Requirement	1
Chapter 2. Hardware Overview.....	2
Chapter 3. Twist HD Camera Setup.....	3
3.1 Before powering on the camera	3
3.2 Powering on the camera	3
3.3 Camera Mode Selection	4
3.4 Adding the Camera to the System	5
3.4.1 Adding Camera to System with Security Shuttle.....	6
3.4.2 Adding Camera to System with Virtual Security Shuttle.....	9
3.4.3 Adding Camera to System with an existing Virtual Security Shuttle	16
3.5 Positioning the camera	23
Chapter 4. Twist HD Camera Settings.....	24
4.1 Display Name.....	25
4.2 Motion Detection	25
4.3 Sound Detection	26
4.4 Live Video Resolution	26
4.5 Wi-Fi	27
4.6 Local Storage.....	27
4.7 Turn On/Off camera	28
4.8 Turn On/Off Continuous Recording.....	28
4.9 Restart/Remove IP Camera	29
4.10 Record Audio	30
Chapter 5. Starting to Use the Twist HD Camera	31
5.1 System/Sensor setting	31
5.1.1 Arm / Disarm / Stay mode Selection.....	31

5.1.2	Sensor setting.....	33
5.1.3	Event Notification and Recording	33
5.2	Viewing the Live Video Feed.....	34
5.3	Viewing the Video Recording	38
Chapter 6. Resetting the Twist HD camera.....		44
Appendix – Glossary of Terms.....		46

Chapter 1. Introduction

The Twist HD Camera is a high definition camera that integrates sensor, live viewing and recording functions onto a single device. These features provide an extra level of security when monitoring your property. Video feeds can be viewed in real-time from the convenience of your smartphone. Whenever a suspicious motion or sound is detected, the camera immediately initiates recording, and the app will send a notification. Thus, wherever you are, you can easily view the recorded event or live feed. Additional highlights include a built-in microphone and speaker for two-way audio and an ultra-wide viewing angle. These designs ensure that all of your needs are met for home security and safety, in-home care, or any other application that requires remote monitoring and recording.

Key features and specifications

- Video resolution : 1280x720
- Automatic night vision
- Expandable flash storage
- Built-in microphone and speaker for two-way audio
- 300° motorized pan
- Tilt: +40° ~ -40° (performed manually)
- Operating temperature : 32°F to 104°F (0°C to 40°C)

1.1 System Requirement

This section explains the system requirement when using the camera.

Network	When camera is connected to Security Shuttle*	Router with <ul style="list-style-type: none">- 10/100Mbps RJ45 LAN port- DHCP service
	When camera is connected directly to Wi-Fi Router	Wi-Fi Router supports <ul style="list-style-type: none">- IEEE 802.11n, 802.11g, 802.11b- WEP/WPA2-PSK Wireless Security
Mobile Device		An Apple iPhone, iPad, or Android mobile device with: <ul style="list-style-type: none">- iOS (version 8.1 above)- Android (version 4.1 above)

* See Appendix – Glossary of Terms.

Chapter 2. Hardware Overview

This section provides an overview of the Twist HD camera and its accessories.



Chapter 3. Twist HD Camera Setup

3.1 Before powering on the camera

If you wish to save the video clips locally or turn on the continuous recording function, a MicroSD card needs to be inserted into the camera. For details about how to check the current storage size of the MicroSD card, see *Section 4.6 – Local Storage*.




Note: Before you insert the MicroSD card into the camera, make sure it has been formatted to FAT 32. Do not insert the MicroSD card into the camera when it is powered on, as this may damage the MicroSD card.

3.2 Powering on the camera


To turn on the camera, complete the following steps.

1. Remove the protective film from the camera lens.
2. Plug the micro USB connector of the USB cable to the camera; then, connect the other end of the cable to the USB power adapter.
3. Plug the USB power adapter into the power outlet to provide power to the camera.
4. The powering-on process first involves the left LED indicator showing a solid blue light. After a few seconds, the right LED indicator will begin to show a flashing purple light; then it will show a flashing blue light, and you will hear “Internet mode”, which is the default setting. The other mode that you can chose is “Local mode”.


①



②



③




3.3 Camera Mode Selection

After the camera is powered on, the default setting will be “Internet mode”. The other mode that you can choose is “Local mode”. To switch between the two modes, short press the button on top of the camera. The switching process takes approximately 25 seconds, and you will hear “Internet mode” or “Local mode”.


Internet mode/Local mode
change button



In “Internet mode”, both LED indicators will show a solid blue light.



In “Local mode”, the left and right LED indicators will respectively show a solid blue and purple light.



3.4 Adding the Camera to the System

Before you begin using the camera, it will need to be added to the system first. This can be done with or without the security shuttle. For details, see the three subsections below.

Important: If you are unable to add the camera to the system or the app shows a message telling you to reset the camera, see *Chapter 6 - Resetting the Twist HD camera* for details.


3.4.1 Adding Camera to System with Security Shuttle

To activate the camera with the security shuttle, complete the following steps.


Note:

- Make sure the Security Shuttle is powered on and connected to your router.
- Make sure the camera is in “Internet mode”.


1. Tap the menu icon  to show the sidebar menu.




2. Tap “Device Management”. If you have more than one security shuttle, you may need to swipe left more than once to find the one you wish the camera to connect to. After selecting the security shuttle, tap the plus icon “+” located to the right of “Camera List”.




3. Select “IP Camera”.



4. Follow the on-screen instructions. When finished, press “Next”.





5. After scanning the QR code located on the bottom of the camera, the “camera adding” process will begin. The process will take approximately 1 to 2 minutes.




6. When the activation is completed, the camera will be added to the device management page. In the illustration shown below, the name of the Security Shuttle is “Location 1” and the name of the camera is

“New Camera”.



7. Both LED indicators on the camera will show a solid blue light.



3.4.2 Adding Camera to System with Virtual Security Shuttle

To add the camera to the system when there is no security shuttle, complete the following steps. The process


will involve the creation of a new virtual security shuttle.

To add the camera to an existing virtual security shuttle, see *Section 3.4.3 - Adding Camera to System with an existing Virtual Security Shuttle*.


Note:

- Make sure your Wi-Fi router is turned on.
- Make sure the camera is in “Local mode”.
- Make sure the Wi-Fi of your smartphone is turned on.


1. Tap the menu icon  to show the sidebar menu; then, tap “Device Management”.



2. Swipe left across the screen and select “IP Camera”. At times, you may need to swipe more than once.



3. Follow the on-screen instructions. When finished, press “Next”.




4. The steps for iOS and Android devices will be different here.


For iOS devices:

After scanning the QR code located on the bottom of the camera, tap “Close”; then, tap “Settings” to access the Wi-Fi settings page to let your smart device connect to the IP camera network. Select the SSID marked as “milife”, followed by “_xxxxxx”; then, follow the subsequent on-screen instructions.

Note: The 6 digit “_xxxxxx” is the product serial number located on the bottom of the camera.



After connecting to the camera network, launch the app again. Select your Wi-Fi network and enter the password if necessary. When finished, tap “Join”.




For Android devices:

After scanning the QR code located on the bottom of the camera, the Wi-Fi settings page will appear to let your smart device connect to the IP camera network. Select the SSID marked as “miife”, followed by “_xxxxxx”.


Note: The 6 digit “_xxxxxx” is the product serial number located on the bottom of the camera.



After connecting to the camera network, tap “Previous”. Select your Wi-Fi network and enter the password. When finished, tap “Join”.




5. Follow the on-screen instructions.




6. After the activation is completed, you will see the message "System is ready" on the screen. By clicking "OK", you will hear "Internet mode", and a virtual Security Shuttle and the camera will be added to the

device management page. In the illustration shown below, the name of the virtual Security Shuttle is “Location 2”, and the name of the camera is “Camera1”.




Note: As the name virtual Security Shuttle implies, there isn't actually a new Security Shuttle. It is merely a virtual creation by the system to bridge the camera to the system.

The  icon represents a virtual Security Shuttle.

The  icon represents an actual Security Shuttle.

7. Both LED indicators on the camera will show a solid blue light.




3.4.3 Adding Camera to System with an existing Virtual Security Shuttle

If you wish to add the camera to an existing virtual security shuttle, complete the following steps.

Note:




- Make sure your Wi-Fi router is turned on.
- Make sure the camera is in “Local mode”.
- Make sure the Wi-Fi of your smartphone is turned on.

1. Tap the menu icon  to show the sidebar menu; then, tap “Device Management”.






2. If you have more than one security shuttle, swipe left across the screen until you find the virtual security shuttle you want the camera to connect to; then, tap the plus icon “+” located to the right of “Camera List” and select “IP Camera”.


For iOS devices:



For Android devices:




3. Follow the on-screen instructions. When finished, press “Next”.




4. The steps for iOS and Android devices will be different here.

For iOS devices: After scanning the QR code located on the bottom of the camera, tap “Close”; then, tap “Settings” to access the Wi-Fi settings page to let your smart device connect to the IP camera network. Select the SSID marked as “milife”, followed by “_xxxxxx”; then, follow the subsequent on-screen instructions.

Note: The 6 digit “_xxxxxx” is the product serial number located on the bottom of the camera.




After connecting to the camera network, launch the app again. Select your Wi-Fi network and enter the password. When finished, tap “Join”.




For Android devices: After scanning the QR code located on the bottom of the camera, the Wi-Fi settings page will appear to let your smart device connect to the IP camera network. Select the SSID marked as “milife”, followed by “_xxxxxx”.


Note: The 6 digit “_xxxxxx” is the product serial number located on the bottom of the camera.




After connecting to the camera network, tap “Previous”. Select your Wi-Fi network and enter the password. When finished, tap “Join”.




5. Follow the on-screen instructions.



6. After the activation is completed, you will see the camera add to your existing virtual shuttle. In the illustration shown below, the name of the camera is "Camera2".



7. Both LED indicators on the camera will show a solid blue light.



Important: If you are unable to add the camera to the system or the app shows a message telling you to reset the camera, see *Chapter 6 - Resetting the Twist HD camera* for details.

3.5 Positioning the camera


After the “camera adding” process has been completed, you can place the device at the desired location. To make sure the connection of the camera is working, you can check the live video feed, and test the motorized pan function. For details about how to view the video feed, see *Section 5.2 – Viewing the Live Video Feed*.


Note:

- Do not manually rotate the camera, as this will damage the device.
- Adjustment of the camera tilt angle needs to be done manually.


Chapter 4. Twist HD Camera Settings

For relevant camera setting adjustments, follow the steps shown below.

1. Tap the menu icon  to show the sidebar menu.
2. Tap “Device Management”; then tap “New Camera” under “Camera List” to reach the “Edit Camera” page.



The following illustrations show the camera settings that can be adjusted.




- Display Name
- Motion Detection
- Sound Detection
- Live Video Resolution
- Wi-Fi
- Local Storage
- Turn On/Off Camera
- Turn On/Off Continuous Recording
- Restart/Remove IP Camera
- Record Audio

4.1 Display Name

This option allows you to change the display name. To do so, tap “Display Name”; then, change the name according to your preference. When finished, tap the check icon located on the upper-right corner.


Note: The maximum length of the display name is 40 characters.



4.2 Motion Detection

This option allows you to change the motion detection sensitivity. To do so, tap “Motion Detection”; then, change the sensitivity according to your preference.

Note: For more sensitive motion detection, set a higher sensitivity level.




4.3 Sound Detection

This option allows you to change the sound detection sensitivity. To do so, tap “Sound Detection”; then, change the sensitivity according to your preference.

Note:

For more sensitive sound detection, set a higher sensitivity level.




4.4 Live Video Resolution

This option allows you to change the live video resolution. To do so, tap “Live Video Resolution”; then, change the resolution according to your preference.

The video resolution for the three different levels is shown below:


- HD: 1280 x 720
- High: 864 x 480
- Medium: 432 x 240



4.5 Wi-Fi


This option allows you to connect to the Security Shuttle via a nearby Wi-Fi router.

If the wireless connection between the camera and Security Shuttle is too weak, you can connect to the Security Shuttle via a nearby Wi-Fi router that has a stronger signal. The router will need to be in the same network as the Security Shuttle. To do so, tap “Wi-Fi”, and choose from the list of available WiFi networks. If necessary, enter the Wi-Fi password.



4.6 Local Storage


To verify that the MicroSD card in the camera is working properly and to view its current storage capacity, tap “Local Storage.”



4.7 Turn On/Off camera


To turn on/off the camera live view function, slide the button to the right or left.

Note: The camera is still able to record triggered events.



4.8 Turn On/Off Continuous Recording

To turn on/off continuous video recording, slide the button to the right or left. This is an intelligent recording function that captures and archives all suspicious motion/sound or sensor-triggered events even when the system is disarmed.



Note:

- When using **OPU3120**, the Twist HD camera begins recording when an event is detected by any of the devices/sensors on the network, or if any of the cameras on the network detect motion or sound. No notification will be sent.
- When using Security **OPU1120** or **OPU2120**, if any of the cameras on the network detects motion or sound, the Twist HD camera begins recording. No notification will be sent.
- The recorded video will consist of a 15 second clip.

Important:

To turn on the continuous recording function, make sure the following requirements are met:

- A MicroSD card must be inserted in the camera.
- Video Motion Detection level needs to be above 0%.


4.9 Restart/Remove IP Camera

To restart the camera, tap “Restart IP Camera”.

To remove the camera from the current Security Shuttle, tap “Remove IP Camera”.

Note:

- Do not unplug the camera until the removal process is completed. For “Internet mode”, the process takes approximately three minutes. When completed, the left LED of the camera will show a solid blue light, while the right LED will show a blinking blue light.
- After the removal process is completed, it will restore the camera to the factory default settings.




4.10 Record Audio

Enables the camera to record nearby audio for both event triggered and continuous recordings.

Note:

- By default, the record audio function will not be turned on due to privacy issues.



Chapter 5. Starting to Use the Twist HD Camera

At this stage, your camera is now ready for use. Due to the built-in camera/sensor functionalities, the device offers the following three main functions:

- **Sound/Motion detection**
- **Live video feed**
- **Video recording**

5.1 System/Sensor setting

This section explains some system/sensor settings you need to configure or check when you begin using the camera as a sensor.


5.1.1 Arm / Disarm / Stay mode Selection

To switch between Arm, Disarm and Stay mode, follow the steps shown below. For details regarding the difference between the three modes, see *Appendix – Glossary of Terms*.


1. Tap the lock icon. The following illustration is an example that shows the system is currently “Armed”.





2. Tap Arm, Disarm or Stay mode.




Note:

- To add a schedule on when to arm/disarm the camera/sensors, tap the  icon; then tap "Schedule" and choose your preferred time period.



- To choose which camera/sensors to arm in Stay mode, tap the  icon; then tap “Stay mode Profile” and choose your preferred devices.



5.1.2 Sensor setting

The ability of the camera to detect suspicious activity will be based on the selected sensitivity level. For details about how to set the motion and sound detection sensitivity level, please proceed to *Section 4.2 Set Motion Detection* and *Section 4.3 Set Sound Detection*.


5.1.3 Event Notification and Recording

If any activity is detected, you will receive an event notification and you can use the live view function to immediately check the event and use the recorded video clip for further verification and analysis.


For details regarding the live view and check video recording functions, see *Section 5.2 - Viewing the Live Video Feed* and *Section 5.3 - Viewing the Video Recording*, respectively.

5.2 Viewing the Live Video Feed


To view the live video feed, tap the “Video” icon; then, tap the video image shown by the camera. If you have more than four cameras, swipe left to see the fifth camera.




Pinch your fingers to zoom in or zoom out when viewing the video feed.







The following describes the various controls.



Advanced camera features: When you tap the camera setting icon, the settings that can be configured will be shown, as seen in the following illustration.



<ul style="list-style-type: none"> • Flip Camera View: Flips the video feed to an inverted view. 	<ul style="list-style-type: none"> • Go to Default Position: Returns the camera back to its default position. 
<ul style="list-style-type: none"> • Motion Detection: Adjusts the motion detection sensitivity. 	<ul style="list-style-type: none"> • Sound Detection: Adjusts the sound detection sensitivity. 


Speaker: Allows you to hear the surrounding sounds near the camera.

Microphone: When you speak towards your smartphone, the camera will broadcast your voice.

Note: The speaker is turned off, by default. If you wish to broadcast your voice using the microphone, first tap the speaker icon; then, tap the microphone icon. When finished, tapping the microphone icon will simultaneously turn off both the microphone and speaker.

Automation control: Used to control various automation devices (for example Smart Plug) in the system.

Recording + social sharing: Begins recording the current video feed and saves the video clip to your smartphone. You can decide whether or not to share on social media outlets.



Emergency call: When you tap this icon, you can select from your list of pre-saved emergency contact numbers who you wish to call.

Note: If you have not set an emergency contact number, see the App manual.


Siren triggering: Manually triggers or dismisses an emergency event via the app.

5.3 Viewing the Video Recording

If a video has been recorded, you can replay the video clip by following the steps shown below. For details about how the system records a video, see *Section 5.1 – System / sensor setting*.


To view recorded events, complete the following steps.

1. Tap the “VideoGram” icon and select the event you wish to check. Events marked with a red dot indicate you have not viewed the event yet.
2. Tap the play icon located in the middle of the screen to watch the recording.




Video recording events from the past three hours can be viewed from the video recording main screen. The grey bar shows the time and date of the recording within a three hour interval, ending at the current time.

All recorded events within the three hour period are shown here.




The following illustration shows you how to navigate the video recording main screen.




For details regarding the four icons located on the bottom of the screen, see the descriptions below.

VideoGram: Takes you to the videoGram menu.





Search: Searches a particular video event detected by the camera(s) or sensor(s).




Replay: Takes you to the replay page to view continuous recorded events.

Note:


- If network problems are encountered while replaying a recording, this icon  will appear on the screen.




- For iOS devices, this animation icon  allows you to swipe up to view more camera clips. The animation icon fades after 10 seconds. Both landscape and portrait views are supported.




- The play icon toggles between playing and pausing the video recording.




- When several video clips are recorded at approximately the same time point, making it difficult to select the one you wish to view, tap the time point to show a list of the video clips. A maximum of six clips are listed, with three clips before and three clips after the selected time point.



Home: Takes you to the app's homepage.




Recorded events are represented by a red line and continuous recorded events are depicted by a grey line.



Chapter 6. Resetting the Twist HD camera

When you are unable to add the camera to the system, or the camera is not working properly, you can try to reset the device. The app may also show a message telling you to do so.



- **Resetting the camera when your camera is not working properly.**

Method 1: Remove the camera from the system. Please see *Section 4.9 – Restart/Remove IP Camera* for details.

Method 2: Open the top cover to find the reset button. Use the end of a paperclip or any pointed object to press the reset button. You will need to hold the button until you hear a “Beep” sound. The resetting process first involves the left LED indicator showing a solid blue light. After a few seconds, the right LED indicator will begin to show a flashing purple light; then it will show a flashing blue light.

- **Resetting the camera when you are unable to add the camera to the system.**

Open the top cover to find the reset button. Use the end of a paperclip to press the reset button. You will need to hold the button until you hear a “Beep” sound.



Note: Resetting the camera will restore your device to factory default settings.

Appendix – Glossary of Terms

- **Arm:** The cameras and other security related sensors in the system are actively monitoring the surroundings. Any suspicious activity that has been detected by the camera or sensor will prompt the app to immediately send a notification. A recording will also be performed by the camera(s) that witnessed the event.
- **Disarm:** The cameras and other security related sensors in the system are no longer actively monitoring the surroundings. The system will not react to any suspicious activity detected by these devices. No notification will be sent.

Note: If the continuous recording function is turned on, video recording will always work regardless if the system is armed or disarmed. For more details regarding the continuous recording function, see *Section 4.8 Turn On/Off Continuous Recording*.

- **Event:** An event is created when any camera or sensor detects an activity, or is manually triggered by the user.
- **Internet mode:** The Twist HD camera is connected to the Internet.
- **Local mode:** The smart device is connected to the Twist HD camera for further configuration.
- **Security Shuttle:** Functions as a secure and intelligent hub to manage the devices and communicate with the cloud server. Currently, there are three types – **OPU1120**, **OPU2120**, and **OPU3120**.
- **Stay Mode:** The system is armed, but only the pre-selected camera and sensors will be actively monitoring the surroundings, and send a notification when any suspicious activity is detected.