


ADD-ON DEVICE

Quickstart Guide

Outdoor External Strobe Siren

Model No. OSR1300

What's inside:



1x Outdoor External Strobe Siren




1x Power Adapter



Mounting Accessories


Broadband internet connection, iOS or Android phone and home router required.

Diagrama de Placa de Circuito Impresso (PCB)



1. Estado/Lentes estroboscópicas de alarme
2. Luz LED de sirene









3. Sirene embutida
4. Interruptor inviolável
5. Adaptador de Interface



6. Bateria de reserva
7. Armador/Desarmador Jumper rapidamente ligado/desligado
8. Jumper de volume da sirene


9. Jumper de tempo da sirene
10. Bloco com fios
11. Interruptor de Ligar/Desligar

Preparação do Jumper

Armar/ Desarmar rapidamente	Ligado (por defeito)	Desligado	
			
Duração da sirene de alarme	30s (por defeito)	2 min	5 min
			
Volume da sirene	Volume alto (por defeito)	Silenciar	Volume baixo
			

Passo 1: instalando dispositivos e acessórios

1. Desembale os dispositivos e acessórios.
2. Empareie o dispositivo com o Shuttle de Segurança dentro da distância de 30cm a 3m para garantir que a conexão funciona bem.
3. Conecte a Sirene na tomada de energia.



Passo 2: Adicionar um dispositivo

1. Abra o aplicativo, toque no botão "☰" e selecione "Gerenciamento de Dispositivo".
2. Pressione o botão adicionar "+" ao lado da Lista de Sensores.
3. Siga as instruções da aplicação para ler o código QR localizado no dispositivo.

Nota: Se a leitura estiver incompleta, será pedido de digite o Número de Série (SN) do dispositivo.

Passo 3: instalando o seu dispositivo

Antes de instalar o dispositivo, ver se ele está dentro do alcance do Shuttle de Segurança.


1. Leve o seu dispositivo para o quarto quer usar.
2. Toque no botão de emergência na tela principal do aplicativo para enviar uma notificação de emergência.

Se a Sirene Externa soar, ela está dentro do alcance, você pode instalar a sirene.


A sua Sirene vem com uma bateria pré-instalada. Por favor, puxe e remova a tira de plástico quando quiser usar a bateria, por exemplo, quando faltar energia.

Instalação


Escolha uma posição adequada numa parede externa, o mais alto possível, onde a sirene possa ser facilmente vista e fora de alcance fácil de qualquer possível vândalo.



- 1 Certifique-se de que o interruptor inviolável pode ser totalmente pressionado na parede




- 2 Use o modelo de montagem fornecido.



- 3 Fure nos três locais indicados.



- 4 Ligue a sirene a uma tomada elétrica.



- 5 Monte a sirene à parede, certificando-se que está bem posicionada.

Troubleshooting Tips

Are your devices listed in your app?

If you're having trouble installing your devices, see if they're listed in your app:

- Navigate to ☰ > **Device Management** to see if all your devices are listed.
- Tap + next to the device category and follow the on-screen instructions to add any missing devices.

Are your devices communicating with Security Shuttle?

- If your devices don't connect to Security Shuttle, they might be too far away. Take them to a location that's closer to Security Shuttle and try again.
- If they do connect, you'll know the range of your device and where to install a range extender.
- Alternatively, you can move Security Shuttle closer to your device.
- If your devices still don't communicate with Security Shuttle, even when they're in the same room, navigate to ☰ > **Device Management** > + on the app to add your devices again.

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



99200306MIG